



## Suggested Actions

Any scale in a boiler is undesirable. The best way to deal with scale is not to let it form in the first place. Prevent scale formation by:

- Pretreating of boiler makeup water (using water softeners, demineralizers, and reverse osmosis to remove scale-forming minerals)
- Injecting chemicals into the boiler feedwater
- Adopting proper boiler blowdown practices

## Clean Boiler Waterside Heat Transfer Surfaces

Even on small boilers, the prevention of scale formation can produce substantial energy savings. Scale deposits occur when calcium, magnesium, and silica, commonly found in most water supplies, react to form a continuous layer of material on the waterside of the boiler heat exchange tubes.

Scale creates a problem because it typically possesses a thermal conductivity an order of magnitude less than the corresponding value for bare steel. Even thin layers of scale serve as an effective insulator and retard heat transfer. The result is overheating of boiler tube metal, tube failures, and loss of energy efficiency. Fuel waste due to boiler scale may be 2% for water-tube boilers and up to 5% in fire-tube boilers. Energy losses as a function of scale thickness and composition are given in the table below.

Energy Loss Due to Scale Deposits*			
Scale Thickness, inches	Fuel Loss, % of Total Use		
	Scale Type		
	“Normal”	High Iron	Iron Plus Silica
1/64	1.0	1.6	3.5
1/32	2.0	3.1	7.0
3/64	3.0	4.7	–
1/16	3.9	6.2	–

Note: “Normal” scale is usually encountered in low-pressure applications. The high iron and iron plus silica scale composition results from high-pressure service conditions.

\*Extracted from *National Institute of Standards and Technology, Handbook 115, Supplement 1*. On well-designed natural gas-fired systems, an excess air level of 10% is attainable. An often stated rule of thumb is that boiler efficiency can be increased by 1% for each 15% reduction in excess air or 40°F reduction in the stack gas temperature.

## Resources

**U.S. Department of Energy**—DOE’s software, the *Steam System Assessment Tool* and *Steam System Scoping Tool*, can help you evaluate and identify steam system improvements. In addition, refer to *Improving Steam System Performance: A Sourcebook for Industry* for more information on steam system efficiency opportunities.

Visit the BestPractices Web site at [www.eere.energy.gov/industry/bestpractices](http://www.eere.energy.gov/industry/bestpractices) to access these and many other industrial efficiency resources and information on training.

## Example

A boiler annually uses 450,000 million Btu (MMBtu) of fuel while operating for 8,000 hours at its rated capacity of 45,000 pounds per hour (lb/hr) of 150-pounds-per-square-inch-gauge (psig) steam. If scale 1/32<sup>nd</sup> of an inch thick is allowed to form on the boiler tubes, and the scale is of “normal” composition, the table indicates a fuel loss of 2%. The increase in operating costs, assuming energy is priced at \$8.00 per million Btu (\$8.00/MMBtu), is:

$$\begin{aligned} \text{Annual Operating Cost Increase} &= 450,000 \text{ MMBtu/yr} \times \$8.00/\text{MMBtu} \times 0.02 \\ &= \$72,000 \end{aligned}$$

## Monitor Flue Gas Temperature

An indirect indicator of scale or deposit formation is flue gas temperature. If the flue gas temperature rises (with boiler load and excess air held constant), the effect is possibly due to the presence of scale.



## Perform Visual Inspections

Visually inspect boiler tubes when the unit is shut down for maintenance. Scale removal can be achieved by mechanical means or acid cleaning. If scale is present, consult with your local water treatment specialist and consider modifying your feedwater treatment or chemical additives schedule.

*Adapted from an Energy TIPS fact sheet that was originally published by the Industrial Energy Extension Service of Georgia Tech.*

BestPractices is part of the Industrial Technologies Program Industries of the Future strategy, which helps the country's most energy-intensive industries improve their competitiveness. BestPractices brings together emerging technologies and best energy-management practices to help companies begin improving energy efficiency, environmental performance, and productivity right now.

BestPractices emphasizes plant systems, where significant efficiency improvements and savings can be achieved. Industry gains easy access to near-term and long-term solutions for improving the performance of motor, steam, compressed air, and process heating systems. In addition, the Industrial Assessment Centers provide comprehensive industrial energy evaluations to small- and medium-size manufacturers.

### FOR ADDITIONAL INFORMATION, PLEASE CONTACT:

EERE Information Center  
1-877-EERE-INF  
(1-877-337-3463)  
[www.eere.energy.gov](http://www.eere.energy.gov)

Industrial Technologies Program  
Energy Efficiency  
and Renewable Energy  
U.S. Department of Energy  
Washington, DC 20585-0121  
[www.eere.energy.gov/industry](http://www.eere.energy.gov/industry)

### ***A STRONG ENERGY PORTFOLIO FOR A STRONG AMERICA***

*Energy efficiency and clean, renewable energy will mean a stronger economy, a cleaner environment, and greater energy independence for America. Working with a wide array of state, community, industry, and university partners, the U.S. Department of Energy's Office of Energy Efficiency and Renewable Energy invests in a diverse portfolio of energy technologies.*

DOE/GO-102006-2252  
January 2006  
Steam Tip Sheet #7

Revised from DOE/GO-10099-952 • June 2001